

R3B Acoustic Panel Instructions & Safety Precautions

This Document will outline installation instructions, safety precautions and care advice.

Installation:

- *What do I need?*

1. A Screw driver or A power drill (preferably cordless) with a philips head bit. Used to fix screws provided onto drywall, concrete or brick. Concrete or brick installation requires pre drilling of the wall with a hammer drill.
2. A simple stud finder to locate studs behind plaster (a “stud” is the timber frame element behind plaster. You will be able to find one stud per meter or so. Stud finders are inexpensive and are available from your local hardware store for around \$15 - \$20.

Instructions: (*drywall*)

1. Use the stud finder to locate any nearby studs around your desired area of the wall. Once a stud is found mark it with a pencil at the desired height.
2. Lift panel onto wall and see if the height you previously marked is OK. Adjust if necessary. Make sure the height of the panel will be out of reach of small children. Once the desired position is found re mark it with a pencil & rescan the area with the stud finder.
3. Now you can screw in the provided screw bit onto the spot you have previously marked. Screw approximately $\frac{3}{4}$ of the way in leaving the smooth

neck of the screw exposed whilst the jagged part all the way in the wall.

4. Now your ready to mount the panel. Lift by holding the rope on the back with one hand and the bottom of the frame with the other hand.
5. Hang the rope off the screw and let go of the panel.
6. Locate the small fixing hole on the centre top of the back of the panel.
7. Place your index finger on the whole whilst your middle finger locates the screw.
8. Once the scew and hole are lined up. Slightly lift and push in to get the panels mounted on the wall flush. YOUR DONE!
9. To unmount panels. Slightly lift and pull out. Let the panel remain suspended off only the rope then lift the panel off the wall from the bottom and from the rope at the same time.

Safety Precautions:

- Do not mount panels directly onto plaster only.
- Do not hang off or lean on panels.
- Do not mount panels on an un-parallel surface.
- Make sure panels are fixed high enough (at least 1 meter off the ground) so that they are out of reach of small children.

Caring & Maintenance:

- Try not to handle panels more than neccessary as the fabric may stretch and ultimately sag.
- You may carefully vacume panels if neccessary or use a static material sweeper to maintain the fabric.

